WARNING: DISCONNECT POWER AT THE MAIN FUSE BOX BEFORE INSTALLATION.

WARNING:

This fixture is intended for installation in accordance with the National Electrical Code (NEC) and all local code specifications. If you are not familiar with code requirements, installation by a certified electrician is recommended.

Before assembly, remove all parts and part packages from box. If anything is missing, please contact the retailer from which the product was purchased.


- 1. Carefully pull house wires out of junction box so they are easily accessible during installation.
- 2. Position mounting bracket (A) so the head of the attached ground screw is pointing down towards floor.
- 3. Place mounting bracket (A) up against junction box. Align each slot in mounting bracket (A) with each hole in junction box.
- 4. Thread each junction box screw (B) into holes in mounting bracket (A) and into holes in junction box. Tighten junction box screws (B) to secure mounting bracket (A) to junction box.

CAUTION: Make sure house wires are still easily accessible. **DO NOT** pinch wires between mounting bracket and ceiling.

- 5. Pass end of fixture wires through hole in center of canopy (D).
- 6. The length of the cord must be adjusted before fixture is installed. Hold canopy (D) against ceiling to determine desired hanging height of fixture.
- If strain relief (V) needs to be repositioned on cord, loosen set screw on strain relief (V). DO NOT completely remove set screw. Slide strain relief (V) up or down the cord (H).




ITEM#: 110-1BL



ITEM#: 110-1BL

- 8. Strip 3/4" of insulation from ends of fixture wires.
- 9. Carefully push fixture wires up through end of threaded pipe on mounting strap (A). Pull fixture wires out of top of threaded pipe.




10. Slightly loosen ground screw on mounting bracket (A). Do not completely remove ground screw. Wrap house ground wire (copper) around ground screw, leaving enough ground wire to attach to fixture ground wire. Twist end of fixture ground wire and end of house ground wire (copper) together. Twist wire nut (C) onto ends of wires. Completely tighten wire nut (C). Reference chart below for correct wire connections.

Connect Supply (House) Ground Copper Wire to:		Connect	vlaguZ	(House)	Ground	Copper	Wire to:
---	--	---------	--------	---------	--------	--------	----------

Bare Copper Wire or,

Bare Silver Wire or,

Green Insulated Wire.



ITEM#: 110-1BL

11. Twist end of house lead wire (black) and end Connect Black Lead Connect White Neutral of fixture lead wire together. Twist wire nut (C) Supply (House) Wire to: Supply (House) Wire to: onto ends of wires. Completely tighten wire nut (C). Twist end of house neutral wire (white) and Black Wire or, White Wire or, end of fixture neutral wire together. Twist wire *Parallel Cord *Parallel Cord nut (C) onto ends of wires. Completely tighten (Round and Smooth) or, (Square and Ridged) or, wire nut (C). Reference chart to the right for correct wire connections. No printed words on Printed words on wire insulation or, wire insulation or, 12. Wrap electrical tape (not included) around wire nuts (C) and wires. Ensure wires are securely Insulated Wire Insulated Wire fastened into wire nuts. (other than green) (other than green) with Copper Conductor. with Silver Conductor. 13. Carefully push all wires and wire nuts into junction box. *When parallel wire (SPT 1 & SPT 2) is used: The lead wire is round in shape or smooth. The neutral wire is square in shape or ridged. FIXTURE LEAD WIRE HOUSE LEAD WIRE (BLACK) FIXTURE GROUND WIRE IOUSE GROUND WIRE (COPPER) 0 FIXTURE NEUTRAL HOUSE NEUTRAL WIRE (WHITE) 14. Raise canopy (D) up to ceiling. Pass hole in D center of canopy (D) over end of threaded pipe on mounting strap (A). 15. Loosen set screw on strain relief (V). Slide strain SET SCREW relief (V) up the cord (H). Thread strain relief (V) onto end of threaded pipe. Tighten strain relief (V) to secure canopy up against ceiling. Tighten set screw on strain relief (V). Η.

ITEM#: 110-1BL

- 16. Squeeze tabs on fixture body in towards socket. Carefully pass hole in top of shade over socket. Fit top of shade over tabs. Carefully release tabs.
- 17. Screw recommended bulb (E12 candelabra bulb type, not included) into socket. Verify correct bulb wattage marked on socket of fixture. **WARNING:** DO NOT exceed maximum bulb wattage.

